INTEGRATION GUIDE





INTEGRATION for TAHOMA® RTS





INTEGRATION GUIDE AMAZON ALEXA INTEGRATION for TAHOMA® RTS VERSION 1.2 | AUGUST 2021 | Prepared by PROJECT SERVICES

TABLE OF CONTENTS

Ι.	OVERVIEW	- 3
	INTRODUCTION	
	RESOURCES & APPLICATIONS	
.	SETUP	- 4
	SMART PHONE or TABLET REQUIREMENTS	
	CONNECTIONS & INDICATORS	
	SYSTEM CONFIGURATION	
	ENABLE SKILLS USING TAHOMA APP	
	ENABLE SKILLS USING ALEXA APP	
	TAHOMA LOG IN & DEVICE DISCOVERY	
	CREATE ROUTINES IN ALEXA	
	DISCOVER DEVICES IN ALEXA	
	REMOVE DEVICES OR SCENES IN ALEXA	
	DISABLE SKILLS IN ALEXA	
APP	ENDIX	9

- A. AVAILABLE COMMANDS & ACTIONS
- B. POSSIBLE VOICE COMMANDS

I. OVERVIEW

INTRODUCTION

The Somfy Organization strength has been demonstrated with 50 years of experience in motorization. As leaders in the shading industry with innovation and modernization solutions for homes and commercial buildings, Somfy offers the widest range of strong, quiet motors and controls for all types of applications and technologies.

Who is this Guide for?

This guide is aimed at providing support and guidance to homeowners, installers and dealers for achieving complete automation of Radio Technology Somfy[®] (RTS) motors and TaHoma[®] Smartphone and Tablet Interface.

What does this Guide contain?

The sections of this guide contain walkthroughs and methods of controlling RTS motors using the TaHoma® Smartphone and Tablet Interface as the bridge between Amazon Alexa and Smart Shading by Somfy.

This guide discusses the method of integration with Amazon Alexa. For questions or assistance please contact technical support: (800) 22-SOMFY (76639) technicalsupport_us@somfy.com

How should this Guide be used?

This guide is intended to be used as a reference manual.

RESOURCES & APPLICATIONS

Visit <u>www.somfypro.com</u> for the following guides:

- Somfy TaHoma Smartphone and Tablet Interface Programming Guide
 - <u>Somfy RTS Pocket Programming Guide</u>

Subscribe to the Somfy YouTube Channel www.youtube.com/somfysystems

Visit the Google Play or iOS App Store for the Somfy TaHoma North America App:









Visit the Google Play or iOS App Store for the Amazon Alexa App:





Google Play Store



iOS App Store

II. SETUP

The Somfy TaHoma[®] Smartphone and Tablet Interface provides a single platform for Somfy RTS and future ecosystems with a wide range of interior and exterior applications.

- The TaHoma[®] Interface supports up to 40 RTS channels
- Install up to 10 interfaces as zone controllers to increase the RTS range
- The TaHoma® can support a maximum of 40 scenes with schedules per install

Each TaHoma Interface is connected to Wi-Fi or directly to the local area network by an optional Ethernet Adaptor for IP Integration with third-party control systems. TaHoma® is compatible with the Somfy Synergy™ API.


Details of this controller and commissioning instruction are available in the Somfy TaHoma Smartphone and Tablet Interface Programming Guide.

SMART PHONE or TABLET REQUIREMENTS

The TaHoma app is compatible with the following operating systems and software versions:

IOS 11.0+ Android 7.0+

CONNECTIONS & INDICATORS



SYSTEM CONFIGURATION

A fully operational TaHoma system is required prior to Amazon Alexa programming. The TaHoma Interface supports up to 40 channels of RTS. RTS devices programmed to an RTS channel will only receive commands from the associated TaHoma Interface. Interfaces must be placed within 25-35' of the RTS devices they control.

- Confirm with Shade Commissioning Agent that the TaHoma Interface firmware is up to date
 - Must have one Amazon account per TaHoma system or project
 - Confirm that Amazon Alexa is powered on and connected to a network with internet

ENABLE SKILLS USING TAHOMA APP

To allow users to create and execute RTS shade Routines in Alexa, follow the steps below:

- 1) SELECT "Menu" from the bottom right-hand corner
- 2) SELECT "Third-Party Integration"
- 3) SELECT "Open the Amazon Alexa App"

Note: Depending on the mobile OS, the appropriate app store will open to download the Alexa App.

Install the app then open Alexa App, then go to the next page ""TaHoma Log in & Device Discovery".

If already installed SELECT Open Alexa app, then go to the next page ""TaHoma Log in & Device Discovery".

	THIRD-PARTY INTEGRATION	AA	🔒 skill	s-store.ama	zon.com	S
💼 TaHoma® 📲 🖷				amazon ale: skill, please us	<mark>ka</mark> ie the Alexa ap	00
My Products		2		Open Alexa		5
My Setup			or do	wnload the Ale	эха Арр	
8 Activity History			TaHo by SOMEY	ma North	America	
Advanced Settings	You can link your account with Amazon Alexa and control your devices without opening the		This skill is c	only for TaHom	a (#1811731)	
Third-Party Integration	TaHoma application.	purchas 2020>>	ed in the Uni		Canada after	January
Legal Information	"Alexa, open my shades"		"Alexa (close the kitch	en shade"	
U Logout	"Alexa, turn kitchen off"					
	To link your Amazon Alexa account with your Somfy account, please click on the link below.					
	Open the Amazon Alexa App					
	OR Visit Somfy's Website for more information					
* 6 6 💮	FAQ Amazon Alexa	<	>	Ċ	Ш	C


Follow the steps on the next page.

ENABLE SKILLS USING ALEXA APP

To allow users to create and execute RTS shade Routines in Alexa, follow the steps below:

From the Amazon Alexa App, ensure the correct account is enabled prior to using the skill. When creating and naming groups in Alexa, refrain from using the same name as the shades.

- 1) SELECT "More" from the bottom right-hand corner
- 2) From the "More" menu, SELECT "Skills & Games" and search for the "TaHoma North America" skill
- In the Amazon Alexa search field, TYPE "Somfy" OR "TaHoma" to find all related TaHoma skills for Alexa
- 4) SELECT "TaHoma North America"
- 5) SELECT "Enable to Use" then go to the next page "TaHoma Log in & Device Discovery"




Follow the steps on the next page.


TAHOMA LOG IN & DEVICE DISCOVERY

To connect a device to Amazon Alexa, follow the steps below:

- 1) Enter TaHoma Login credentials previously used to Register during TaHoma Programming
- 2) SELECT "LOGIN"
- 3) SELECT "YES" to authorize Alexa to access the Somfy account



- 4) Under Account Linking: SELECT "CLOSE"
- 5) Under Discover Devices: SELECT "DISCOVER DEVICES"
- 6) After 45 secs, screen will read "No new devices found" SELECT "CLOSE"




All RTS shades and scenes paired and created in TaHoma will display in the Alexa App under Devices automatically.

To disable the TaHoma Skill, refer to the DISABLE SKILLS IN ALEXA section of this Guide.

CREATE ROUTINES IN ALEXA

Routines are series of actions from one or more devices triggered by a single voice command, by time of day, or by other devices or sensors.

To create the "Alexa, Breakfast time" voice routine, follow the steps below:



The first Routine is now created for TaHoma.

Test the routine: "Alexa, Breakfast Time"

It may take up to 1 minute for voice routines to be ready to use.

DISCOVER DEVICES IN ALEXA

If an RTS shade needs to be added to Alexa, follow the steps below:

DEVICES

(Ð)

- 1) SELECT "Devices" from the bottom navigation bar
- 2) SELECT "+"
- 3) SELECT "Add Device"
- 4) SCROLL and SELECT "Other"

Which device would you like to set up? Headphones Echo & Alexa Scenes · All Devices GROUPS Coffee Maker Office Printer Car Accessory Development Device YOUR SMART HOME SKILLS Air Conditioner Air Purifier × Add Device Fan Add Group S Other . 9 -0 ¢ = 0 (Devices) 9 _____ Combine speakers


0

<

SETUP

0

- 5) SELECT "Discover Devices" Alexa will look for devices to connect (This may take up to 45 Seconds)
- 6) SELECT "Set Up Device"
- 7) SELECT "Done"




The RTS devices are now discovered.

REMOVE DEVICES OR SCENES IN ALEXA

If an RTS shade or a scene is no longer required to be triggered by Alexa, follow the steps below:

DELETE AN RTS SHADE -

- 1) SELECT "Devices" from the bottom navigation bar
- 2) SELECT "All Devices"
- 3) SELECT the RTS Shade to be deleted Example: "Kitchen"
- 4) SELECT "Trash Bin" in the top right-hand corner
- 5) SELECT "Delete" to confirm



DELETE A SCENE -

- 1) SELECT "Devices" from the bottom navigation bar
- 2) SELECT "Scenes"
- 3) SELECT the Scene to be deleted *Example: "Goodnight"*
- 3) SELECT "Trash Bin" in the top right-hand corner
- 4) SELECT "Delete" to confirm

SCENES	< SCENE SETTINGS	SCENE SETTINGS
	Goodnight Edit Name	Goodnight Edit Name
fternoon	ABOUT	ABOUT
	Connected Via SOMEY	> Connected Via SOMPY
ood Morning	Description Scene connected via TaHoma	Description Scene connected via TaHoma
oodnight	Type Scene	Type Scene Remove "Goodnight"? This also removes your scene from all
Discover Scenes	Enabled	Enablec Enablec
LEARN MORE		Cancel Delete
• 0 0 =	Ξ • Ο Δ	= • • • • •
ene Camenaichte Play Devices Mo		Hune Conversionate Play Devices Marr

The RTS Shade or Scene is now deleted.

To rediscover the deleted RTS Shade or Scene, refer to the DISCOVER DEVICES IN ALEXA section of this guide.


DISABLE SKILLS IN ALEXA

Disabling a skill can be used when Alexa voice activation is no longer required, if new devices added in TaHoma are not being discovered in Alexa, or if a device or scene has been removed in the Alexa app while the Alexa device is powered off.

When disabling TaHoma North America Skill, Alexa will no longer recognize any RTS shades, scenes or routines associated with TaHoma.

To disable skills in Alexa, follow the steps below:

- 1) SELECT "More" from the bottom right-hand corner
- 2) SELECT "Skills & Games"
- 3) SELECT "Your Skills"
- 4) SELECT "TaHoma North America"
- 5) SELECT "DISABLE SKILL"



The skill is now disabled.

APPENDIX

[APPENDIX A] AVAILABLE COMMANDS & ACTIONS

TAHOMA RTS BLIND		
Open/Raise	Moves blind to the fully open position	
Close/Lower	Moves blind to the fully closed position	

[APPENDIX B] POSSIBLE VOICE COMMANDS

WINDOW COVERINGS (rolling shutters, exterior and interior blinds and screens)		
Open/Raise	"Alexa, open the bedroom blinds" or "Alexa, raise the bedroom blinds"	
Close/Lower	"Alexa, close the bedroom blinds" or "Alexa, lower the bedroom blind"	

SCENE COMMANDS				
ON	"Alexa, turn on Good Morning" or "Alexa, turn on Everything Up"			
Scene names can be found in the TaHoma app. Create new scenes or to rename existing ones to perfect				
the experience with Amazon Alexa.				

GROUP COMMANDS			
Open	"Alexa, open Bedroom Group" or "Alexa, open kitchen"		
Close	"Alexa, close Bedroom Group" or "Alexa, close kitchen"		
Groups can be created in the Alexa App. More information is available at <u>http://tinyurl.com/alexa-smart-home-groups</u>			

ABOUT SOMFY

SOMFY® has been improving everyday life for more than 270 million people by designing and manufacturing intelligent motorization solutions for interior window coverings and exterior solar protections. Somfy innovates to automate and connect shades, blinds, draperies, awnings, rolling shutters, exterior screens & pergolas for commercial and residential buildings in 58 countries across the globe. With 170+ million motors produced over the last half century, Somfy is committed to creating reliable and sustainable solutions that promote the best way of living and well-being for all.

FOR QUESTIONS OR ASSISTANCE PLEASE CONTACT TECHNICAL SUPPORT:

(800) 22-SOMFY (76639) technicalsupport_us@somfy.com

SOMFY SYSTEMS INC SOMFY NORTH AMERICAN HEADQUARTERS

121 Herrod Blvd. Dayton, NJ 08810 P: (609) 395-1300 F: (609) 395-1776

FLORIDA

1200 SW 35th Ave. Boynton Beach, FL 33426 F: (561) 995-7502

CALIFORNIA

15301 Barranca Parkway Irvine, CA 92618-2201 F: (949) 727-3775

SOMFY ULC

SOMFY Canada Division 5178 Everest Drive Mississauga, Ontario L4W2R4 P: (905) 564-6446 F: (905) 238-1491

www.somfypro.com

A BRAND OF **SOMFY⁵** GROUP

